

Lab report: Measuring Young's modulus and Poisson's ratio of a metal wire

TiankaiMa PB21000030

October 18, 2022

Abstract

Both Young's modulus and Poisson's ratio reflect important properties of a material. In this experiment, we take a metal wire as a target to present a way to measure both quantities.

Keywords: Young's modulus, Poisson's ratio

Introduction

Young's modulus is an important mechanical parameter of a material that reflects the amount of resistance to deformation. Stress is defined as the ratio of the tensile force F to the original cross-section A , and the ratio of ΔL to the original length L is defined as the longitudinal line strain. In the elastic range, this could be described as a linear relationship named Hooke's Law:

$$\frac{F}{A} = E \cdot \frac{\Delta L}{L} \quad (1)$$

Only longitudinal strain in the material is considered in the equation above, we define the transverse line strain as the ratio of the transverse variation Δd to the transverse length d . Experiment shows that they follow a linear relationship:

$$\frac{\Delta d}{d} = -\mu \cdot \frac{\Delta L}{L} \quad (2)$$

The negative sign shows that longitudinal stretching leads to transverse shrinkage and vice versa.

Notice that the Δd is way too small to measure, we can measure the resistivity $\rho \propto 1/d^2$.

In this experiment, we also need to use an unbalanced bridge to measure the small change in resistance, illustrated as follows:




Figure 1: unbalanced bridge used to measure resistance

When U_g is balanced out, the bridge follows that: $R_1/R_2 = R_3/(R_4 + R_s)$, where the R_s is changing when the wire stretches. We can use this equation to calculate the resistance R_s : When given a change of $\Delta R_s \leq (R_4 + R_s) \cdot 1\%$, the bridge approximately follows:

$$U_g \approx \frac{U_{AC}}{4} \cdot \frac{\Delta R_s}{R_4 + R_s} \quad (3)$$

Materials

Connect the circuit as the unbalanced bridge shows, where $R_1 = R_2 = R_3 = 51.00\Omega$, and connect R_4 into a resistance box.

Mesaure both U_g and U_{AC} , keep $U_{AC} \sim (0.3V, 0.5V)$, change R_4 to make the bridge balanced (when $|U_g| < 0.020mV$ is considered balanced).

To measure Young's modulus, the change in length also needs to be measured with a reading microscope pointing at the solder joint W.

Results

$$\begin{aligned}D &= 0.2mm \\R_4 + R_s &= 51.00\Omega \\L_1 + L_2 &= 121.2cm \\L_2 &= 26.8cm \\V_{AC} &= 0.400V \\R_4 &= 14.97\Omega\end{aligned}\tag{4}$$

Images are attached in a separate paper.

Discussion

$$\begin{aligned}R_s &= \rho \frac{L}{A} \\ \frac{\Delta d}{d} &= -\mu \cdot \frac{\Delta L}{L} \\ \frac{\Delta R_s}{R_s} &= (1 + 2\mu) \frac{\Delta L}{L} \\ U_g &= \frac{U_{AC}}{4} \cdot \frac{\Delta R_s}{R_4 + R_s} \\ \Delta R_s &= 4(R_4 + R_s) \cdot \frac{U_g}{U_{AC}}\end{aligned}\tag{5}$$

For that we can conclude:

$$U_g = \frac{U_{AC}}{4} \cdot \frac{R_s \cdot (1 + 2\mu) \cdot \frac{\Delta L}{L}}{R_4 + R_s} = \frac{U_{AC} R_s (1 + 2\mu)}{4(R_4 + R_s)} \Delta L\tag{6}$$

Young's modulus:

$$E = \frac{\pi R^2 k_{\Delta L \sim m}}{g(L_1 + L_2)} = 2.288 \times 10^{-11} E/Pa\tag{7}$$

Poisson's ratio:

$$\mu = \frac{1}{2} \left(\frac{4k(R_s + R_4)}{R_s U_{AC}} - 1 \right) = 0.237\tag{8}$$

The accepted value of Young's modulus E is $2.0E/10^{11}pa$, accepted value of poisson's ratio is 0.3.

References

Most contents were translated from the handout.

Images




Figure 2: $U_g \sim \Delta L$




Figure 3: $\Delta L \sim \Delta m$